


# SensorTile Game Controller in Unity

Final Project Presentation  
Babak Damadi

# Introduction

- Hand-free game controller using SensorTile: play
  - User's motions simulating control input from a gamepad/joystick
- Motion Pattern Recognition with Embedded ML:
  - Fast, lightweight, and independent to the integrated game engine (e.g. can work with Unity, HTML5 game)
- Utilize wireless communication: BLE and Wifi
  - Hand-free game controller is cordless, indeed.

# Components



- A BeagleBone is used to receive SensorTile's data, process, and forward to Unity.
- BeagleBone communicates with SensorTile via BLE connection.
- Unity (or may any other program) communicates with BeagleBone using WebSocket protocol.

# Basic Game Controller



- D-Pad Buttons [1][2][3][4]
- Button A [5]
- Button B [6]
- Train an ANN to detect and classify 6 motions
- Features are extracted from Gyroscope sensor
- Embedded ML (1) running on SensorTile's processor

# Contributions


- SensorTile Firmware: deploys a ML model to classify 6 motion patterns and BLE communication
- A server program running on BeagleBone:
  - connect to SensorTile's BLE using gatttool
  - Host a web socket server
- A demo game scene implemented in Unity:
  - Connect to BeagleBone (via WS) to send train request and receive detected motions

# Motion Pattern Recognition

- Base on STMicroelectronics SensorTile Tutorial 13 - Rotation Angle Classification with Machine Learning
- Modify the program of Tutorial 13 to update the program flow and add BLE communication with a connected device, e.g. BeagleBone:
  - Receive command to for training step.
  - Send detected motion in running step
- Experiment with the ANN for detecting 6 different motions based on changing in rotation angle.

# Proposed Motion Gestures

- Based on changing in rotation angle in relative to the starting position of the SensorTile.
- 6 motion gestures for 6 buttons:
  - Tilt the SensorTile about X or Y axis for D-pad buttons
  - Rotate the SensorTile about Z-axis clockwise and counter-clockwise for Button A and B.




# Feature Data Acquisition: Rotation Angle

- Collect SensorTile's rotation rate sensor microgyroscope with sampling period of 0.01 seconds to measure rotation angle (for X, Y and Z axes)
  - Up to 1 second (maximum 100 data acquisition cycles).
  - Or the rotation angle magnitude exceed the threshold of 30 degrees
- Normalize feature values



# Neural Network Topology



# Performance Assessment

- The ANN was successfully trained in 60-80 epochs with z-score threshold of 1.
- The ANN successfully detected 6 motions as shown in the demo video.
- However, the motion pattern depends on the initial position of the SensorTile - Require user to return to the starting position to perform next motion.

Training Epochs: 60

State 0	Max 57	Mean 16	Z-score 128	Outputs 57	-40	18	22	18	23
State 1	Max 55	Mean 12	Z-score 170	Outputs -19	55	21	-1	9	9
State 2	Max 41	Mean 17	Z-score 134	Outputs 16	20	41	-13	19	20
State 3	Max 36	Mean 10	Z-score 154	Outputs 21	-8	-4	36	9	10
State 4	Max 53	Mean 15	Z-score 141	Outputs 25	8	23	7	53	-27
State 5	Max 61	Mean 13	Z-score 171	Outputs 14	3	16	12	-23	61
Index 0	Error State: 0								

# Questions